



★ MELBOURNE ★
WATCH COMPANY

SORRENTO AUTOMATIC

OWNER'S HANDBOOK



WELCOME TO OUR JOURNEY...

Thank you for purchasing your Melbourne Watch Company timepiece.

Since our establishment in 2013, we have strived to create timepieces of the highest quality that you as an owner can be proud of wearing.

Each MWC timepiece represents a new stage in our journey as a brand as we continue to evolve and grow – A journey that we are glad to have you on board for.

Sujain Krishnan
Managing Director, Founder

CONTENTS

Model Specifications	3
Operating Instructions	5
Steel Bracelet Adjustment	7
Customer Support	9



SORRENTO AUTOMATIC

Dive meets dress with our Sorrento collection, combining the multi-layered ceramic dial construction of the Portsea collection with a rugged dive watch case and a unique double layered engraved bezel.

The Sorrento also features 20ATM water resistance, Japanese super-lume and a solid steel bracelet with quick-release end-links.

TECHNICAL SPECIFICATIONS

Case Material:	316L Stainless Steel
Case Diameter:	42mm
Case Thickness:	14mm
Lug Width:	22mm
Movement:	Sellita Cal. SW200 Automatic
Power Reserve:	40 Hours Maximum
Beat Rate:	28,800bph
Functions:	12-Hour Time, Date, Dive Bezel
Crystal:	Flat Anti-Reflective Sapphire
Water Resistance:	200m/20ATM
Strap:	316L Bracelet





OPERATING INSTRUCTIONS

Your Sorrento timepiece is fitted with the Sellita SW-200 (Swiss Made) high-beat automatic movement.

The crown may be placed in 3 positions as per the image below and must be unscrewed prior to time adjustment.

- A. Fully pushed in – when in this position, the crown can be rotated clockwise to manually wind the movement after being unscrewed
- B. Partially pulled out – The middle crown position allows for the date to be adjusted by clockwise rotation.
- C. Fully pulled out – when in this position, the crown can be rotated in both directions to set the time.



Notes:

1. To unscrew the crown, rotate it counter-clockwise.
2. To screw in the crown, apply pressure towards the case and rotate it clockwise
3. Do not manually adjust the date during the automatic change-over action as this may damage the gearing in the mechanism



STEEL BRACELET ADJUSTMENT

The Sorrento comes with a steel bracelet that may be adjusted in two ways, as per the instructions below.

1. Each side of the bracelet has links which may be removed using a jeweller's screwdriver. We advise performing link removal first prior to any micro-adjustments as per option (2) below.
2. The deployment clasp contains several 'micro-adjustment' steps. The end-link of the bracelet can be moved incrementally across these steps by using a bracelet pin tool.

We recommend having a professional jeweller or watchmaker perform any bracelet adjustments to avoid damage to your bracelet or deployment clasp.



WARRANTY INFORMATION

All watches purchased from Melbourne Watch Company come with a 24-month manufacturer's warranty.

This warranty covers material production defects concerning the watch, strap and movement.

It does not cover damage caused through misuse/physical force, or normal wear and tear.

Your warranty will be valid from the date of purchase and will be noted on a warranty card included with your order when shipped.

Your warranty will be rendered void if any attempts are made to repair or modify your timepiece without prior consent from us.

If you have an issue with your timepiece, please notify us via our website and we will do our best to assist you in resolving it as quickly as possible.

WWW.MELBOURNEWATCH.COM.AU/PAGES/CONTACT



★ MELBOURNE ★
WATCH COMPANY

W: melbournewatch.com.au

E: info@melbournewatch.com.au